

WHELEN[®]

ENGINEERING COMPANY INC.

ROUTE 145, WINTHROP ROAD
 CHESTER, CONNECTICUT 06412-0684
 TELEPHONE: (860) 526-9504
 FAX: (860) 526-4078

Grill Bracket Mounting Instruction Sheet: SA122DB / SP123DB & SA314 Siren Speakers, Models: 1992 and Newer Chevrolet S-10 Blazer, Blazer, Tahoe And Suburban

Mounting:

1. First mount the siren box to the mounting bracket using the supplied hardware.

NOTE: When mounting the siren box to the mounting bracket, make sure that the wire exit hole is positioned toward the bottom of the unit for drainage purposes. (See warning)

2. Locate the passengers side tow hook underneath the front bumper of your vehicle. Remove and retain the 2 hex head bolts that secure the tow hook to the vehicle's frame.
3. With the siren box secured to the mounting bracket, position the bracket in its mounting location as shown.
4. Place the 1/2" split lockwashers (supplied) onto the previously removed hex head bolts and insert them through the bracket, through the tow hook and into the frame. Tighten hex head bolts firmly.
5. Run the WHITE (Positive) and BLACK (Negative) speaker wires to your siren amplifier and connect as outlined in the amplifier's instructions.
6. Test the siren for proper operation.

CAUTION

Loud siren noise
 Can cause
 Hearing loss



Minimize exposure
 Close windows when using

WARNING: For drainage purposes both the siren box's wire passage hole and the siren drivers drain hole must be located on the bottom for proper mounting. Improper mounting will not only result in driver failure, but will also void the product warranty.

