

# WHELEN<sup>®</sup>

ENGINEERING COMPANY INC.

51 Winthrop Road  
Chester, Connecticut 06412-0684  
Phone: (860) 526-9504  
Fax: (860) 526-4078  
Internet: [www.whelen.com](http://www.whelen.com)  
Sales e-mail: [autosale@whelen.com](mailto:autosale@whelen.com)  
Canadian Sales e-mail: [autocan@whelen.com](mailto:autocan@whelen.com)  
Customer Service e-mail: [custserv@whelen.com](mailto:custserv@whelen.com)

**Installation Guide:**  
**“Quick Disconnect” Mounting Brackets**  
**1999 Dodge Caravan & Plymouth Voyager**  
**1999 Grand Caravan & Grand Voyager**  
**1999 Chrysler Town & Country**

## Safety First

This document provides all the necessary information to allow your Whelen product to be properly and safely installed. Before beginning the installation and/or operation of your new product, the installation technician and operator must read this manual completely. Important information is contained herein that could prevent serious injury or damage.

- **Proper installation of this product requires the installer to have a good understanding of automotive electronics, systems and procedures.**
- **If mounting this product requires drilling holes, the installer MUST be sure that no vehicle components or other vital parts could be damaged by the drilling process. Check both sides of the mounting surface before drilling begins. Also de-burr any holes and remove any metal shards or remnants. Install grommets into all wire passage holes.**
- **If this manual states that this product may be mounted with suction cups, magnets, tape or Velcro®, clean the mounting surface with a 50/50 mix of isopropyl alcohol and water and dry thoroughly.**
- **Do not install this product or route any wires in the deployment area of your air bag. Equipment mounted or located in the air bag deployment area will damage or reduce the effectiveness of the air bag, or become a projectile that could cause serious personal injury or death. Refer to your vehicle owner’s manual for the air bag deployment area. The User/Installer assumes full responsibility to determine proper mounting location, based on providing ultimate safety to all passengers inside the vehicle.**
- **For this product to operate at optimum efficiency, a good electrical connection to chassis ground must be made. The recommended procedure requires the product ground wire to be connected directly to the NEGATIVE (-) battery post.**
- **If this product uses a remote device to activate or control this product, make sure that this control is located in an area that allows both the vehicle and the control to be operated safely in any driving condition.**
- **Do not attempt to activate or control this device in a hazardous driving situation.**
- **This product contains either strobe light(s), halogen light(s), high-intensity LEDs or a combination of these lights. Do not stare directly into these lights. Momentary blindness and/or eye damage could result.**
- **Use only soap and water to clean the outer lens. Use of other chemicals could result in premature lens cracking (crazing) and discoloration. Lenses in this condition have significantly reduced effectiveness and should be replaced immediately. Inspect and operate this product regularly to confirm its proper operation and mounting condition. Do not use a pressure washer to clean this product.**
- **It is recommended that these instructions be stored in a safe place and referred to when performing maintenance and/or reinstallation of this product.**
- **FAILURE TO FOLLOW THESE SAFETY PRECAUTIONS AND INSTRUCTIONS COULD RESULT IN DAMAGE TO THE PRODUCT OR VEHICLE AND/OR SERIOUS INJURY TO YOU AND YOUR PASSENGERS!**

**For warranty information regarding this product, visit [www.whelen.com/warranty](http://www.whelen.com/warranty)**

## **Installation:**

These brackets has been designed to fit into the outer channels that run along the roof of your 1999 Dodge Caravan, Grand Caravan, Plymouth Voyager, Grand Voyager and Chrysler Town & Country. The procedures outlined herein are simple, however failure to measure accurately will result in a poor installation that could prevent your lightbar from being properly mounted. Be sure to confirm that all measurements are correct before drilling.

**WARNING!** *This installation will require drilling. It is absolutely necessary to make sure that nothing will be damaged in the process. If damage is possible, select another location.*

1. Place the brackets into the outermost chanel in the roof, at the location you will want the lightbar to sit. It is usually recommended that the bar be centered approximately over the front door.
2. Measure the distance from the front of the roof to the two brackets to make sure the two brackets are both the same distance from the front of the vehicle.
3. Mark off the location of the screw holes with a pencil or marker.
4. Remove the brackets and drill the mounting holes with an appropriately sized drill, for the screws supplied. Be careful selecting a drill bit as the screws will need to thread into these holes to hold the lightbar on the car.

**Note:** Make sure to choose a drill bit small enough so that the screw will thread tightly into the hole you drill. Also apply silicone sealer between the bracket and roof to properly seal the holes from moisture.

5. Attach both brackets to the roof with the mounting screws provided.
6. The lightbar strap attaches to the brackets as shown. Refer to your lightbar mounting manual information on attaching the strap to the lightbars mounting foot.

