

WHELEN[®]

ENGINEERING COMPANY INC.

51 Winthrop Road,
Chester, Connecticut 06412-0684
Phone: (860) 526-9504
Fax: (860) 526-4078

Installation Guide: LINZ6™ Rear Deck Mounting Bracket 2010 Crown Victoria

Internet: www.whelen.com
Sales e-mail: autosale@whelen.com
Canadian Sales e-mail: autocan@whelen.com
Customer Service e-mail: custserv@whelen.com

IMPORTANT! It is the responsibility of the installation technician to make sure that the installation and operation of this product will not interfere with or compromise the operation or efficiency of any vehicle equipment!

Installation:

1. On the rear deck, locate the 2 outboard caps covering the child restraint strap holders. Remove the plastic covers to access the tether strap holders (Fig. 1).
2. Install the mounting bracket as shown in Fig 2. **Be sure to tighten the mounting hardware firmly.**
3. Secure the lighthead to the mounting bracket as shown using the provided hardware. Confirm that the lighthead is level and clears the 3rd brake light.
4. Extend the lighthead wires to your power source. It is left to the installation technician's discretion to select a path for the wires that will not damage them or interfere with the operation of any vehicle components or equipment.

5. Refer to the lighthead manual for wiring and fusing.

WARNING! All customer supplied wires that connect to the positive terminal of the battery must be sized to supply at least 125% of the maximum operating current and be FUSED at the battery to carry that load. DO NOT USE CIRCUIT BREAKERS WITH THIS PRODUCT!

IMPORTANT! Before returning the vehicle to active service, visually confirm the proper operation of this product, as well as all vehicle components/equipment.

IMPORTANT WARNING!

CAUTION! DO NOT LOOK DIRECTLY AT THESE LED'S WHILE THEY ARE ON. MOMENTARY BLINDNESS AND/OR EYE DAMAGE COULD RESULT!

©2010 Whelen Engineering Company Inc.
Form No.14378 (050610)

For warranty information regarding this product, visit www.whelen.com/warranty

WHELEN[®]

ENGINEERING COMPANY INC.

51 Winthrop Road,
Chester, Connecticut 06412-0684
Phone: (860) 526-9504
Fax: (860) 526-4078

Installation Guide: LINZ6™ Rear Deck Mounting Bracket 2010 Crown Victoria

Internet: www.whelen.com
Sales e-mail: autosale@whelen.com
Canadian Sales e-mail: autocan@whelen.com
Customer Service e-mail: custserv@whelen.com

IMPORTANT! It is the responsibility of the installation technician to make sure that the installation and operation of this product will not interfere with or compromise the operation or efficiency of any vehicle equipment!

Installation:

1. On the rear deck, locate the 2 outboard caps covering the child restraint strap holders. Remove the plastic covers to access the tether strap holders (Fig. 1).
2. Install the mounting bracket as shown in Fig 2. **Be sure to tighten the mounting hardware firmly.**
3. Secure the lighthead to the mounting bracket as shown using the provided hardware. Confirm that the lighthead is level and clears the 3rd brake light.
4. Extend the lighthead wires to your power source. It is left to the installation technician's discretion to select a path for the wires that will not damage them or interfere with the operation of any vehicle components or equipment.

5. Refer to the lighthead manual for wiring and fusing.

WARNING! All customer supplied wires that connect to the positive terminal of the battery must be sized to supply at least 125% of the maximum operating current and be FUSED at the battery to carry that load. DO NOT USE CIRCUIT BREAKERS WITH THIS PRODUCT!

IMPORTANT! Before returning the vehicle to active service, visually confirm the proper operation of this product, as well as all vehicle components/equipment.

IMPORTANT WARNING!

CAUTION! DO NOT LOOK DIRECTLY AT THESE LED'S WHILE THEY ARE ON. MOMENTARY BLINDNESS AND/OR EYE DAMAGE COULD RESULT!

©2010 Whelen Engineering Company Inc.
Form No.14378 (050610)

For warranty information regarding this product, visit www.whelen.com/warranty

