

51 Winthrop Road

Chester, Connecticut 06412-0684

Phone: (860) 526-9504 Fax: (860) 526-4078

Sales Email:autosale@whelen.com

Canadian Sales:canadiansales@whelen.com Customer Service:custserv@whelen.com

Safety First: This document provides all the necessary information to allow your Whelen product to be properly and safely installed. Before beginning the installation and/or operation of your new product, the installation technician and operator must read this manual completely. Important information is contained herein that could prevent serious injury or damage.

- Proper installation of this product requires the installer to have a good understanding of automotive electronics, systems and procedures.
- Whelen Engineering requires the use of waterproof butt splices and/or connectors if that connector could be exposed to moisture.
- Any holes, either created or utilized by this product, should be made both air- and watertight using a sealant recommended by your vehicle manufacturer.
- Failure to use specified installation parts and/or hardware will void the product warranty!
- If mounting this product requires drilling holes, the installer MUST be sure that no vehicle components or other vital parts could be damaged by the drilling process. Check both sides of the mounting surface before drilling begins. Also de-burr any holes and remove any metal shards or remnants. Install grommets into all wire passage holes.
- Do not install this product or route any wires in the deployment area of your air bag.
 Equipment mounted or located in the air bag deployment area will damage or
 reduce the effectiveness of the air bag, or become a projectile that could cause
 serious personal injury or death. Refer to your vehicle owner's manual for the air
 bag deployment area. The User/Installer assumes full responsibility to determine
 proper mounting location, based on providing ultimate safety to all passengers
 inside the vehicle.
- For this product to operate at optimum efficiency, a good electrical connection to chassis ground must be made. The recommended procedure requires the product ground wire to be connected directly to the NEGATIVE (-) battery post.

- If this product uses a remote device to activate or control this product, make sure that this control is located in an area that allows both the vehicle and the control to be operated safely in any driving condition.
- Do not attempt to activate or control this device in a hazardous driving situation.
- This product contains either strobe light(s), halogen light(s), high-intensity LEDs or a combination of these lights. Do not stare directly into these lights. Momentary blindness and/or eye damage could result.
- Use only soap and water to clean the outer lens. Use of other chemicals could result in premature lens cracking (crazing) and discoloration. Lenses in this condition have significantly reduced effectiveness and should be replaced immediately. Inspect and operate this product regularly to confirm its proper operation and mounting condition. Do not use a pressure washer to clean this product.
- WARNING! All customer supplied wires that connect to the positive (+) terminal of the battery must be sized to supply at least 125% of the maximum operating current and FUSED "at the battery" to carry that load. DO NOT USE CIRCUIT BREAKERS WITH THIS PRODUCT!
- FAILURE TO FOLLOW THESE PRECAUTIONS AND INSTRUCTIONS COULD RESULT IN DAMAGE TO THE PRODUCT OR VEHICLE AND/OR SERIOUS INJURY TO YOU AND YOUR PASSENGERS!

Installation

- Using the dimensions below, mark the mounting and wire hole locations onto the proposed mounting surface. Drill two, .250" diameter mounting holes and a .625" (minimum) wire access hole into the mounting surface.
- 2. Place the appropriate gasket into position on the rear of the F9 assembly (see Gasket Note). NOTE: On the back of the gasket, the word "BOTTOM" shows the correct orientation. Insert the slotted hole screw grommet through the mounting holes on the F9/Gasket assembly. Feed the F9 wires through the wire access hole in the mounting surface. Press the F9/Gasket/Grommet assembly onto its mounting location so that it is flat against the mounting surface.
- 3. With the assembly in position and using the hardware provided, tighten the mounting screws until the lighthead assembly is drawn firmly against the mounting surface. DO NOT OVERTIGHTEN!
- Using appropriately sized wires (minimum 18 AWG), extend the F9 wires to their designated connections. Refer to the diagram below for wiring and fusing information.

Wiring...

Back-Up Model

Connect the WHITE wire to the POSITIVE output wire of the back-up light circuit. Connect the BLACK (12V) or BLK/WHT (24V) wire to GROUND.


B/T/T Model

Connect the YELLOW wire to the POSITIVE output wire of brake light circuit. Connect the BROWN wire to the POSITIVE output wire of the tail light circuit. Connect the WHITE (12V) or WHT/BLK (24V) wire to GROUND. The WHT/VIO wire is used to configure the brake light display. See below.

Arrow Model

Connect the *LED Color* wire to +VBAT. Fuse this wire @ 3 Amps. Connect the BLACK (12V) or BLK/WHT (24V) wire to GROUND. The WHT/VIO wire is used to change patterns. See below.

WHITE/VIO - Scan-Lock™ Pattern Selection: This feature allows the user to select between the available patterns. Note that the Lighthead must be on in order for Scan-Lock to work. Momentarily apply +VBAT to the WHT/VIO wire to change patterns:



Arrow Model

- 1. Steady On
- 2. Sequence (150 fpm) to Solid
- 3. Sequence (80 fpm) to Solid
- 4. Sequence (Fast) to Solid-Steady On
- 5. Sequence (Slow) to Solid-Steady On
- 6. SingleFlash 75
- 7. ModuFlash™
- 8. Signal-Alert™ to Steady On

B/T/T Model

- 1. Steady
- 2. SignalAlert™ Steady

IMPORTANT WARNING!

CAUTION! DO NOT LOOK DIRECTLY AT THESE LEDS WHILE THEY ARE ON. MOMENTARY BLINDNESS AND/OR EYE DAMAGE COULD RESULT!

Warnings to Installers

Whelen's emergency vehicle warning devices must be properly mounted and wired in order to be effective and safe. Read and follow all of Whelen's written instructions when installing or using this device. Emergency vehicles are often operated under high speed stressful conditions which must be accounted for when installing all emergency warning devices. Controls should be placed within convenient reach of the operator so that he can operate the system without taking his eyes off the roadway. Emergency warning devices can require high electrical voltages and/or currents. Properly protect and use caution around live electrical connections. Grounding or shorting of electrical connections can cause high current arcing, which can cause personal injury and/or vehicle damage, including fire. Many electronic devices used in emergency vehicles can create or be affected by electromagnetic interference. Therefore, after installation of any electronic device it is necessary to test all electronic equipment simultaneously to insure that they operate free of interference from other components within the vehicle. Never power emergency warning equipment from the same circuit or share the same grounding circuit with radio communication equipment. All devices should be mounted in accordance with the manufacturer's instructions and securely fastened to vehicle elements of sufficient strength to withstand the forces applied to the device. Driver and/or passenger air bags (SRS) will affect the way equipment should be mounted. This device should be mounted by permanent installation and within the zones specified by the vehicle manufacturer, if any. Any device mounted in the deployment area of an air bag will damage or reduce the effectiveness of the air bag and may damage or dislodge the device. Installer must be sure that this device, its mounting hardware and electrical supply wiring does not interfere with the air bag or the SRS wiring or sensors. Mounting the unit inside the vehicle by a method other than permanent installation is not recommended as unit may become dislodged during swerving; sudden braking or collision. Failure to follow instructions can result in personal injury. Whelen assumes no liability for any loss resulting from the use of this warning device. PROPER INSTALLATION COMBINED WITH OPERATOR TRAINING IN THE PROPER USE OF EMERGENCY WARNING DEVICES IS ESSENTIAL TO INSURE THE SAFETY OF EMERGENCY PERSONNEL AND THE PUBLIC.

Warnings to Users

Whelen's emergency vehicle warning devices are intended to alert other operators and pedestrians to the presence and operation of emergency vehicles and personnel. However, the use of this or any other Whelen emergency warning device does not guarantee that you will have the right-of-way or that other drivers and pedestrians will properly heed an emergency warning signal. Never assume you have the right-of-way. It is your responsibility to proceed safely before entering an intersection, driving against traffic, responding at a high rate of speed, or walking on or around traffic lanes. Emergency vehicle warning devices should be tested on a daily basis to ensure that they operate properly. When in actual use, the operator must ensure that both visual and audible warnings are not blocked by vehicle components (i.e.: open trunks or compartment doors), people, vehicles, or other obstructions. It is the user's responsibility to understand and obey all laws regarding emergency warning devices. The user should be familiar with all applicable laws and regulations prior to the use of any emergency vehicle warning device. Whelen's audible warning devices are designed to project sound in a forward direction away from the vehicle occupants. However, because sustained periodic exposure to loud sounds can cause hearing loss, all audible warning devices should be installed and operated in accordance with the standards established by the National Fire Protection Association.