





## REPLACEMENT PARTS

ITEM	PART NUMBER	DESCRIPTION
14	02-0250276-03	FLASH TUBE ASSEMBLY (MOLEX CONNECTOR)
13	02-0250276-00	FLASH TUBE ASSEMBLY (A610)
12	68-2290005-30	LENS, FLASHTUBE (A612)
11	19-170052-009	RETAINER, LENS (A626)
10		#6-32 X 5/16 PHILLIPS FHMS(MS51959-27)
9	02-0350072-55	LENS/RETAINER ASSY. (RED)
8	02-0350003-01	BASE PLATE ASSEMBLY (W1285-2)
7	38-0130106-00	GASKET, FLASHTUBE, (A427-3)
6	38-0230021-00	GASKET, LENS (W1283)
5	34-0414020-65	LAMP, 14V (W129014)
4	34A0428020-65	LAMP, 28V (W1290-28)
3	68-4230020-40	LENS, GREEN (W1284G)
2	68-4230020-50	LENS, RED (W1284R)
1	02-0350072-35	LENS/RETAINER ASSY., CLEAR (A626D)
ITEM	PART NUMBER	DESCRIPTION