


ROUTE 145, WINTHROP ROAD  
CHESTER, CONNECTICUT 06412-0684  
TELEPHONE: (860) 526-9504  
FAX: (860) 526-4078



### SPECIFICATIONS

INPUT VOLTAGE	INPUT CURRENT	LAMP POWER
13.5 VDC	2.4 AMPS	32 W
13.5 VDC	2.9 AMPS	39 W
13.5 VDC	4.3 AMPS	58 W
26.5 VDC	1.3 AMPS	35 W

QTY.	QTY.	ITEM	PART NUMBER	DESCRIPTION
-	*	-	01-0661848__0__	56 SERIES HALOGEN WITHOUT CABLE
*	-	-	01-0661848__1__	56 SERIES HALOGEN WITH CABLE
1	1	1	68-1181783-A0	LENS / OPTIC DIRECTIONAL / AMBER
A/R	A/R	2	68-1181783-B0	LENS / OPTIC DIRECTIONAL / BLUE
A/R	A/R	3	68-1181783-C0	LENS / OPTIC DIRECTIONAL / CLEAR
A/R	A/R	4	68-1181783-G0	LENS / OPTIC DIRECTIONAL / GREEN
A/R	A/R	5	68-1181783-R0	LENS / OPTIC DIRECTIONAL / RED
1	1	6	38-0261637-00	LENS GASKET
1	1	7	02-0261854-00	REFLECTOR SUB-ASSEMBLY / 14V-32W
A/R	A/R	8	02-0261854-01	REFLECTOR SUB-ASSEMBLY / 14V-39W
A/R	A/R	9	02-0261854-02	REFLECTOR SUB-ASSEMBLY / 14V-58W
A/R	A/R	10	02-0261854-03	REFLECTOR SUB-ASSEMBLY / 28V-35W
1	1	11	38-0541804-00	EXTRUDED MODEL #56 GASKET
-	1	12	46-0920802-00	INPUT CONNECTOR ASSEMBLY
1	-	13	02-0240624-15	15' CABLE ASSEMBLY
1	-	14	01-0415532-00	CABLE INSTALLATION KIT

### MOUNTING INSTRUCTIONS:

- First, hold the reflector against the mounting surface and mark the 3 mounting holes off onto the mounting surface. **IMPORTANT:** Be sure the lens mounting screw is positioned at the top of the lighthead as shown.
- Drill the 3 mounting holes using a drill bit sized for a #6 sheet metal screw.
- Drill a hole in the approximate center of the mounting area for the power wire to pass through. **NOTE:** You should install a rubber grommet (customer supplied) to protect the wire.
- Run the power wire through the wire hole and to your power source, then mount the lighthead as shown. Be sure the gap in the mounting gasket is on the bottom.

**WARNING:** All customer supplied wires that connect to the positive terminal of the battery must be sized to supply at least 125% of the maximum operating current and fused at the battery to carry the load.

**WARNING:** To avoid personal injury do not attempt to replace the lamp with fingers. Use the lamp replacement tool included with the kit.

**NOTE:** The outer surfaces of this product may be cleaned with mild soap and water. The use of any other chemicals may void the product warranty. Do not use a pressure washer.

### ORDERING INFORMATION

EXAMPLE OF PART NUMBER:

01-0661848-1 R 2

└─ CABLE OPTION  
└─ LENS COLOR  
└─ LAMP / VOLT. & WATT.

LENS COLOR    LAMP VOLTAGE    CABLE OPTION  
A = AMBER      AND WATTAGE    0 = NO CABLE  
B = BLUE       0 = 14V - 32 WATT    1 = WITH CABLE  
C = CLEAR      1 = 14V - 39 WATT  
G = GREEN      2 = 14V - 58 WATT  
R = RED         3 = 28V - 35 WATT