

WHELEN[®]

ENGINEERING COMPANY INC.

51 Winthrop Road
Chester, Connecticut 06412-0684
Phone: (860) 526-9504
Fax: (860) 526-4078
Internet: www.whelen.com
Sales e-mail: autosale@whelen.com
Canadian Sales e-mail: autocan@whelen.com
Customer Service e-mail: custserv@whelen.com

**SL6 Power Supply Kit
Retro-Fit Procedures
for Edge[®] models:
9004SL/AK 9004WB 9801, 9802,
9804, 9804AK, Mini Edge[®]**

Safety First

This document provides all the necessary information to allow your Whelen product to be properly and safely installed. Before beginning the installation and/or operation of your new product, the installation technician and operator must read this manual completely. Important information is contained herein that could prevent serious injury or damage.

- **Proper installation of this product requires the installer to have a good understanding of automotive electronics, systems and procedures.**
- **If mounting this product requires drilling holes, the installer MUST be sure that no vehicle components or other vital parts could be damaged by the drilling process. Check both sides of the mounting surface before drilling begins. Also de-burr any holes and remove any metal shards or remnants. Install grommets into all wire passage holes.**
- **If this manual states that this product may be mounted with suction cups, magnets, tape or Velcro[®], clean the mounting surface with a 50/50 mix of isopropyl alcohol and water and dry thoroughly.**
- **Do not install this product or route any wires in the deployment area of your air bag. Equipment mounted or located in the air bag deployment area will damage or reduce the effectiveness of the air bag, or become a projectile that could cause serious personal injury or death. Refer to your vehicle owner's manual for the air bag deployment area. The User/Installer assumes full responsibility to determine proper mounting location, based on providing ultimate safety to all passengers inside the vehicle.**
- **For this product to operate at optimum efficiency, a good electrical connection to chassis ground must be made. The recommended procedure requires the product ground wire to be connected directly to the NEGATIVE (-) battery post.**
- **If this product uses a remote device to activate or control this product, make sure that this control is located in an area that allows both the vehicle and the control to be operated safely in any driving condition.**
- **Do not attempt to activate or control this device in a hazardous driving situation.**
- **This product contains either strobe light(s), halogen light(s), high-intensity LEDs or a combination of these lights. Do not stare directly into these lights. Momentary blindness and/or eye damage could result.**
- **Use only soap and water to clean the outer lens. Use of other chemicals could result in premature lens cracking (crazing) and discoloration. Lenses in this condition have significantly reduced effectiveness and should be replaced immediately. Inspect and operate this product regularly to confirm its proper operation and mounting condition. Do not use a pressure washer to clean this product.**
- **It is recommended that these instructions be stored in a safe place and referred to when performing maintenance and/or reinstallation of this product.**
- **FAILURE TO FOLLOW THESE SAFETY PRECAUTIONS AND INSTRUCTIONS COULD RESULT IN DAMAGE TO THE PRODUCT OR VEHICLE AND/OR SERIOUS INJURY TO YOU AND YOUR PASSENGERS!**

For warranty information regarding this product, visit www.whelen.com/warranty

Table of Contents

Retro-Fit guidelines for models (with a ZS or 1ZS, 5ZS or ZSM Power Supply): 9004SL/AK, 9004WB, 9801, 9802, 9804, 9806, Mini Edge®.....	page 3
Retro-Fit guidelines for models (with a ZSO, 1ZSO or 2ZSO Power Supply): 9004SL/AK, 9004WB, 9801, 9802, 9804, 9806, Mini Edge®.....	page 4
SL6 Power Supply and Adaptor Harness Information	page 5
SL6 Specification Table.....	page 5
Adaptor Cable Usage Table	page 5

Section 1; Retro-Fit guidelines for the following:

Models:

9004SL, 9004WB, 9801, 9802,
9804, 9806, 9004AK, Mini Edge®

With Power Supply:

ZS, 1ZS, 5ZS OR ZSM

WARNING!!!

The strobe light power supply is a **HIGH VOLTAGE** device. You must wait at least 10 minutes after turning off the power to the system before starting any diagnostic or trouble shooting procedures that may bring you into contact with any internal components.

Removal of Existing Power Supply...

1. Remove endcap and lenses until you have access to your lightbar's power supply. Power supply is located in the center section of your lightbar.
2. Locate and remove the two screws that hold the power supply in position and remove the power supply from the lightbar.
3. Locate the five harness plugs that connect to the existing power supply. As shown in Fig. 1, four function plugs are connected to color-labeled outlets at one end of the power supply, while a larger plug is connected to a fused plug at the other end.




Fig. 1

4. Each of the function plugs has a key wire whose color corresponds to the color label for that plug's outlet. Take note of each plug's key color, as it will be used to identify that plug for connection to the new power supply.

Installation of New Power Supply...

1. Before the new power supply can be installed in the lightbar, a harness adaptor must be added as follows.

2. Locate the "2ZFO/ZF Output Harness Adaptor" shown in Fig. 2 (P/N - 46-0745715-00). This adaptor will be connected to plugs 2 & 3 of the new power supply. **NOTE - Make sure that the adaptor harness is installed so that the wire colors of the adaptor plugs are lined up with the wire colors of the power supply's plugs.**
3. With the appropriate adaptor harness plugged onto the new power supply, the new power supply can now be connected to the lightbar. Connect the lightbar's 4-position power plug to Plug 1. Now locate the harness plugs that were connected to the old power supply and connect to the adaptor harness as follows:

Lightbar Plug with:

RED WIRE to
WHITE WIRE to
BLUE WIRE to
GREEN WIRE to

Adaptor Plug with:

RED WIRE
WHITE WIRE
BLUE WIRE
GREEN WIRE

4. The new power supply may now be mounted in the lightbar. Position the new power supply in its mounting location. This will be a tight fit and will require a small amount of effort to properly mount the new power supply. **NOTE: If harness wraps are present on the old lightbar plug harnesses, it may be necessary to carefully cut and remove these wraps in order for the power supply to fit into the extrusion.**
5. Secure the power supply to the lightbar using the old power supply's mounting screws. **NOTE: Apply Loctite™ #242 to the threads of each mounting screw.**
6. Test the lightbar for proper operation. After a successful test, the lightbar may be reassembled in the reverse order in which it was disassembled.
7. If the lightbar does not function properly, disconnect the lightbar from its power source, wait 10 minutes to avoid the risk of a high voltage shock and confirm that the proper plugs are connected. If the plugs connections are correct, contact your Whelen representative for further assistance.

IMPORTANT NOTE!: SEE PAGE 5 FOR IMPORTANT INFORMATION ON NEW/LOW POWER ACTIVATION PROCEDURE.

Section 4; Retro-Fit guidelines for the following:

Models:

9004SL, 9004WB, 9801, 9802,
9804, 9806, 9004AK, Mini Edge®

With Power Supply:

ZSO, 1ZSO or 2ZSO

WARNING!!!

The strobe light power supply is a **HIGH VOLTAGE** device. You must wait at least 10 minutes after turning off the power to the system before starting any diagnostic or trouble shooting procedures that may bring you into contact with any internal components.

Removal of Existing Power Supply...

1. Remove endcap and lenses until you have access to your lightbar's power supply. Power supply is located in the center section of your lightbar.
2. Locate and remove the two screws that hold the power supply in position and remove the power supply from the lightbar.
3. Locate the three harness plugs that connect to the existing power supply. Before disconnecting these plugs from the power supply, write down each of the the wire colors that were connected to each plug. This is important, as this will determine how these plugs are connected to the new power supply.
4. Remove power supply from lightbar.

Installation of new Power Supply...

1. The new power supply is connected to the lightbar without any adaptor cables. When connecting the lightbar plugs to the new power supply, make sure that the wire colors match exactly.
2. The new power supply may now be mounted in the lightbar. Position the new power supply in its mounting location. This may be a tight fit and could require a small amount of effort to properly mount the new power supply. **NOTE: If harness wraps are present on the old lightbar plug harnesses, it may be necessary to carefully cut and remove these wraps in order for the power supply to fit into the extrusion.**
3. Secure the power supply to the lightbar using the old power supply's mounting screws. **NOTE: Apply Loctite™ #242 to the threads of each mounting screw.**
4. Test the lightbar for proper operation. After a successful test, the lightbar may be reassembled in the reverse order in which it was disassembled.
5. If the lightbar does not function properly, disconnect the lightbar from its power source, wait 10 minutes to avoid the risk of a high voltage shock and confirm that the proper plugs are connected. If the plugs connections are correct, contact your Whelen representative for further assistance.

IMPORTANT NOTE!: SEE PAGE 5 FOR IMPORTANT INFORMATION ON NEW/LOW POWER ACTIVATION PROCEDURE.

SPECIFICATIONS

INPUT VOLTAGE	- 13.5 VDC ±20%
INPUT CURRENT OFF	- 0 AMPS
INPUT CURRENT 30 WATTS	- 3 AMPS (TYP)
INPUT CURRENT 60 WATTS	- 6 AMPS (TYP)
INPUT CURRENT 90 WATTS	- 9 AMPS (TYP)
FLASHRATE (CometFlash®)	- 75 FPM (PER LAMP) @ 85 ms
FLASHRATE (DOUBLEFLASH)	- 110 FPM (PER LAMP) @ 100 ms
FLASHRATE (SINGLEFLASH)	- 240 FPM (PER LAMP)
FLASHRATE (SEQUENTIAL)	- 3 CYCLES (COMET) > 4 CYCLES (SF)
INPUT CONTROL VOLTAGE	- 13.5 VDC ±20%
INPUT CONTROL CURRENT	- 50 MA (TYP)
ENERGY 60 WATT MODE	- 26.5 JOULES (TOTAL) 11.5/5/5/5 JOULES
ENERGY 90 WATT MODE	- 36 JOULES (TOTAL) 15/7/7/7 JOULES
ENERGY LO POWER MODE	- 10 JOULES (TOTAL) 2.5/2.5/2.5/2.5 JOULES

IF YOU HAVE LIGHTBAR #:	WITH POWER SUPPLY #:	USE ADAPTOR CABLE:
9004SL, 9004WB, 9801, 9802, 9804, 9806, 9004AK, Mini Edge®	ZS, 1ZS, 5ZS OR ZSM	46-0745715-00
9004SL, 9004WB, 9801, 9802, 9804, 9806, 9004AK, Mini Edge®	ZSO, 1ZSO OR 2ZSO	NONE

Fig. 2

**Plug 1:
Input Control**


PIN #	COLOR	FUNCTION	CONTROL
1	RED	INPUT VOLTAGE	13.5 VDC 20%
2	BLACK	GROUND	GROUND
3	VIOLET	LOW POWER	N/C - HI POWER (MOM) +12V - LO POWER
4	GREEN	P2 DISABLE	13.5 VDC ±20%

**Plug 2:
Front Modules**

PIN #	COLOR	FUNCTION
1	ORANGE	ANODE
2	ORANGE	ANODE
3	BLACK/WHITE	CATHODE
4	BLACK/WHITE	CATHODE
5	GREEN	TRIGGER
6	WHITE	TRIGGER

**Plug 3:
Rear Modules**

PIN #	COLOR	FUNCTION
1	ORANGE	ANODE
2	ORANGE	ANODE
3	BLACK/WHITE	CATHODE
4	BLACK/WHITE	CATHODE
5	BLUE	TRIGGER
6	RED	TRIGGER



NOTICE!!!

Wiring Change: **Revision of Low Power Operation**

The Low Power Control Wire (Violet Colored) is now grounded to prevent accidental initiation of the LOW INTENSITY MODE. In order to activate the Low Power Mode:

1. Cut the VIOLET wire in the Power Cable.
2. Add a length (appropriate size) of 18 AWG wire.
3. Connect the additional wire to a Single Pole/Single Throw **momentary** switch to +12 Volt DC fused@3 Amps.

To restore HIGH POWER MODE, turn lightbar off for at least two seconds and then turn the lightbar on.

