

WHELEN[®]

ENGINEERING COMPANY INC.


51 Winthrop Road,
Chester, Connecticut 06412-0684
Phone: (860) 526-9504

Internet: www.whelen.com
Sales e-mail: autosale@whelen.com
Customer Service e-mail: custserv@whelen.com

Installation Guide:

TA1664, TA8864 Series traffic Advisor™

⚠ WARNING: This product can expose you to chemicals including Methylene Chloride which is known to the State of California to cause cancer, and Bisphenol A, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.



©1998 Whelen Engineering Company Inc.
Form No.13368B (011917)

For warranty information regarding this product, visit www.whelen.com/warranty

WARNING!

The installation of this light array is not complete until the upper and lower wings on both ends of the array are secured to the vehicle using the supplied extrusion step bolts (see illustration at left).

Failure to properly secure the light array could cause possible damage to the array and the vehicle.

Note: Optional, non-standard length cables are not for use with either 'Sequence to Solid' or 'Sequence On/Off' flash patterns.

- Part List:**
1. HEX NUT
 2. 3/8" LOCKWASHER
 3. 3/8" FLAT WASHER
 4. NYLON SPACER
 5. STEP BOLT

WHELEN[®]

ENGINEERING COMPANY INC.


51 Winthrop Road,
Chester, Connecticut 06412-0684
Phone: (860) 526-9504

Internet: www.whelen.com
Sales e-mail: autosale@whelen.com
Customer Service e-mail: custserv@whelen.com

Installation Guide:

TA1664, TA8864 Series traffic Advisor™

⚠ WARNING: This product can expose you to chemicals including Methylene Chloride which is known to the State of California to cause cancer, and Bisphenol A, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.



©1998 Whelen Engineering Company Inc.
Form No.13368B (011917)

For warranty information regarding this product, visit www.whelen.com/warranty

WARNING!

The installation of this light array is not complete until the upper and lower wings on both ends of the array are secured to the vehicle using the supplied extrusion step bolts (see illustration at left).

Failure to properly secure the light array could cause possible damage to the array and the vehicle.

Note: Optional, non-standard length cables are not for use with either 'Sequence to Solid' or 'Sequence On/Off' flash patterns.

- Part List:**
1. HEX NUT
 2. 3/8" LOCKWASHER
 3. 3/8" FLAT WASHER
 4. NYLON SPACER
 5. STEP BOLT