WWW.WHELEN.com ENGINEERING COMPANY

51 Winthrop Road

Chester, Connecticut 06412-0684

Phone: (860) 526-9504

Sales Email:autosale@whelen.com

Canadian Sales:canadiansales@whelen.com

Customer Service:custserv@whelen.com

Safety First: This document provides all the necessary information to allow your Whelen product to be properly and safely installed. Before beginning the installation and/or operation of your new product, the installation technician and operator must read this manual completely. Important information is contained herein that could prevent serious injury or damage.

- Proper installation of this product requires the installer to have a good understanding of automotive electronics, systems and procedures
- Whelen Engineering requires the use of waterproof butt splices and/or connectors if that connector could be exposed to moisture.
- Any holes, either created or utilized by this product, should be made both air- and watertight using a sealant recommended by your vehicle manufacturer.
- Failure to use specified installation parts and/or hardware will void the product warranty!
- If mounting this product requires drilling holes, the installer MUST be sure that no vehicle components or other vital parts could be damaged by the drilling process. Check both sides of the mounting surface before drilling begins. Also de-burr any holes and remove any metal shards or remnants. Install grommets into all wire passage holes. Do not install this product or route any wires in the deployment area of your air bag.
- Equipment mounted or located in the air bag deployment area will damage or reduce the effectiveness of the air bag, or become a projectile that could cause serious personal injury or death. Refer to your vehicle owner's manual for the air bag deployment area. The User/Installer assumes full responsibility to determine proper mounting location, based on providing ultimate safety to all passengers inside the vehicle.
- For this product to operate at optimum efficiency, a good electrical connection to chassis ground must be made. The recommended procedure requires the product ground wire to be connected directly to the NEGATIVE (-) battery post.

- If this product uses a remote device to activate or control this product, make sure that this control is located in an area that allows both the vehicle and the control to be operated safely in any driving condition.
- Do not attempt to activate or control this device in a hazardous driving situation.
- This product contains either strobe light(s), halogen light(s), high-intensity LEDs or a combination of these lights. Do not stare directly into these lights. Momentary blindness and/or eye damage could result.
 - Use only soap and water to clean the outer lens. Use of other chemicals could result in premature lens cracking (crazing) and discoloration. Lenses in this condition have significantly reduced effectiveness and should be replaced immediately. Inspect and operate this product regularly to confirm its proper operation and mounting condition. Do
- not use a pressure washer to clean this product. WARNING! All customer supplied wires that connect to the positive (+) terminal of the battery must be sized to supply at least 125% of the maximum operating current and <u>FUSED</u> "at the battery" to carry that load. DO NOT USE CIRCUIT BREAKERS WITH THIS
- FAILURE TO FOLLOW THESE PRECAUTIONS AND INSTRUCTIONS COULD RESULT IN DAMAGE TO THE PRODUCT OR VEHICLE AND/OR SERIOUS INJURY TO YOU AND YOUR PASSENGERS!

Mounting:

1. Using the dimensions below, mark the mounting and wire hole locations onto the proposed mounting surface. Drill two, .250" diameter mounting holes and a .625" (minimum) wire access hole into the mounting surface. 2. Place the gasket into position on the rear of the M6 assembly (see gasket note

the M6/Gasket assembly so that it is flush with the lens.

3. Feed the M6 wires through the wire access hole in the mounting surface. Press the M6/Gasket/Grommet assembly onto its mounting location so that it is flat against the mounting surface.

below). Insert the slotted hole screw grommet through the mounting holes on

- 4. With the assembly in position and using the hardware provided, tighten the mounting screws until the lighthead assembly is drawn firmly against the mounting surface. A torque value of 12 in-lb. (max.) is typically required to achieve this. WARNING: DO NOT OVER TIGHTEN!
- 5. Using appropriately sized wires (minimum 18 AWG), extend the M6 wires to their designated connections. Refer to the diagram below for wiring and fusing information.

Wiring: Back-Up Model

Connect WHT wire to (+) 10-30V output wire of the back-up light circuit.

Connect BLK wire to GROUND. **B/T/T Model**

Connect YEL wire to (+) 10-30V output wire of brake light circuit.

Connect BRN wire to (+) 10-30V output wire of the taillight circuit. Connect WHT wire to GROUND.


Turn Signal Model

Connect ORG or WHT/ORG wire to (+)10-30V output wire of the turn signal circuit. Connect BLK wire to GROUND.

Connect WHT/VIO wire to to a momentary switch and extend the wire to (+)10-30V. Fuse wire @ 1 Amp.

NOTE: Connecting the ORG wire will put the Turn Signal in front

intensity when activated and connecting the WHT/ORG wire will put the Turn Signal in rear intensity when activated. Do not connect both wires at once or the lighthead will not function.



This feature allows the user to select from the available patterns. Lighthead must be on in order for Scan-Lock™ to work. Momentarily apply (+) 10-30V to the WHT/VIO wire to change patterns:

1. Steady On (Arrow) 2. Sequence (120 FPM) to Solid 3. Sequence (80 FPM) to Solid

TURN SIGNAL Model

4. Sequence (Fast) to Solid - Steady On 5. Sequence (Slow) to Solid - Steady On

6. Steady On (Solid) AMP 3 POS PIN POS 1 - WHITE

3 POS DEUTSCH SOCKET POS. A - BROWN POS. B - YELLOW POS. C - WHITE AMP 3 POS PIN POS 1 - BROWN POS 2 - YELLOW POS 3 - WHITE BACKUP 3 POS DEUTSCH SOCKET POS. A - WHITE POS. B - CAVITY SEAL

POS 2 - N/C POS 3 - BLACK TURN SIGNAL 3 POS DEUTSCH SOCKET POS. A - WHT/ORG POS. B - ORANGE POS. C - BLACK CAP - WHT/VIO AMP 3 POS PIN POS 1 - WHT/ORG

POS 2 - ORANGE

POS 3 - BLACK CAP - WHT/VIO

IMPORTANT WARNING! CAUTION! DO NOT LOOK DIRECTLY AT

THESE LEDS WHILE THEY ARE ON. MOMENTARY BLINDNESS AND/OR EYE DAMAGE COULD RESULT!

©2021 Whelen Engineering Company Inc. Form No. 14D45 (010821)